

Technical Bulletin

 FIRE-LITE® ALARMS
by Honeywell

Powering D350RPL Duct Detectors from MS-9050UD AUX Power

FLTB07-09-01

Dear Valued Customer,

It has come to our attention that aux power outputs (NAC-1 or NAC-2 defined as aux power supply) cannot be used to power more than one D350RPL duct detector. These devices can be powered from either an AC or DC source.

When a DC source from the NAC output is used from the MS-9050UD, the device is not compatible. Customers are advised to power D350RPL duct detectors from a separate DC or AC source.

For further information or assistance, please contact Fire-Lite technical support Monday through Friday 8:00AM - 5:00PM Eastern Standard Time, 1-800-627-3473 to speak to a technician or you can e-mail your questions to:
firelite.tech@honeywell.com.

Sincerely,



Nick Martello
Fire-Lite Marketing Director